1. Open your Smartphone Wifi settings and copy the relevant information (IP Address, Subnet Mask, Router, DNS).

Settings   Wi-Fi

Wi-Fi

✓ sav

CHOOSE A NETWORK...

marketing

NETGEAR11

SFR WiFi FON

SFR WiFi Mobile

SFR_75A8

VAGASIEGE

wlanaccessv2.0

Wi-Fi   sav

Forget this Network

IP ADDRESS

DHCP	BootP	Static

IP Address	192.168.2.43
Subnet Mask	255.255.255.0
Router	192.168.2.1
DNS	192.168.2.1

Search Domains

Client ID

Renew Lease

2. When you install your scale, click on Set up Wi-Fi connection.

Network setup

YOUR SCALE CAN JOIN A WIRELESS
NETWORK TO SYNC WITH YOUR
WITHINGS ACCOUNT

Set up Wi-Fi connection   >

I don't have a Wi-Fi Network   >

If you don't have a Wi-Fi network, your
readings will be uploaded in Bluetooth

3. If the following popup is displayed, tap Ignore.

4. Enable the Manual configuration.

5. Paste the information you copied during step 1. For the IP address, copy/paste the 7 first numbers and add ".250" (see below).